

# **Operations Manual**

# Pump Series: 600

Model #610-450

- ➢ 610 Pump Head
- <sup>1</sup>/<sub>4</sub> HP Geared Pneumatic Drive

# Randolph Austin Company Peristaltic Pumps

#### WHY CHOOSE A PERISTALTIC PUMP?

Peristaltic pumps work by using a flexible tubing inside a raceway, which is alternately compressed by a set of rotating rollers. This flexing action insulates the materials being transferred from the moving parts of the pump. The advantages are important when transferring sterile solutions, abrasives, inks or any other fluid, which would ordinarily contaminate or destroy the internal components of a pump. Because of the action of the Randolph pump, it is an excellent choice for shear sensitive fluids and applications where fluid metering is necessary.

#### PERFORMANCE PARAMETERS

Several factors such as viscosity, pressure, speed, pump configuration, and tubing selection, influence the flow rate of a Randolph pump. These factors must be considered to determine the selection of a pump.

Fluids with increased viscocity will result in reduced flow rates. Careful consideration needs to be made to the distance and height of the pump relative to fluids being pumped, especially if they are viscous. The further the pump is from the source, the greater the flow loss.

The discharge pressure capabilities of the Randolph pump will vary with the type and size of tubing selected as well as the operating conditions of the pump. Excessive discharge pressure may rupture tubing or reduce the effective tubing life.

Tubing selection must consider the fluid compatibility, temperature, and pressure, which the pumping application will see. It is recommended that the tubing be immersed in the fluid to be pumped for a minimum of 24 hours as a method of determining chemical compatibly. However, there is no guarantee that tubing which passes a "soak" test will perform in the same manner inside the pump. The soak test, while providing valuable information, does not replicate the dynamic situation inside the pump.

# WHY YOU SHOULD CHOOSE A RANDOLPH PERISTALTIC PUMP

Randolph pumps are manufactured to exacting tolerances with high quality materials. The rugged construction of the Randolph pump makes it an ideal choice for applications where trouble free performance is necessary.

With over forty years' experience, in peristaltic pumps, Randolph Austin Company has a proven track record of value and service to our customers.

#### STANDARD CONSTRUCTION


Randolph pumpheads are available in a variety of material constructions. Models 250, 500, 610, and 750 are machined from aluminum housings and use stainless steel internal components for corrosion and wear resistance. The model 880 pump is machined from an aluminum casting, and uses plated steel components for its impeller plate and shaft.


#### STAINLESS STEEL MODELS


Randolph Austin Company offers the 615 and 755 model pumps in a 316 stainless steel housing. This material is well suited for washdown applications. Model 615 and 755 pumps have the same performance characteristics as the standard model 610 and 750 pumps respectively.

#### PLASTIC PUMP HEADS.

The 300 and 400 series pumps housings are made from polycarbonate. These pumps offer the O.E.M. cost effective, quality units to incorporate into their design. The 300 series pump is designed to mount directly of motor and can be configured in a variety of forms. The 400 series pump is a panel mount pump with a standard three-impeller roller yoke and hinged side cover. The 400 series is the newest pump in the Randolph Austin catalog.







#### General Recommendations: Air Motor: #03-0362 - 1/4 Hp Geared Air Motor

#### General Usage Guidelines:

- Only compressed air should be used to drive the motor.
- Air lines that feed the motor should be the same size, or the next size bigger, as the inlet port for efficient output and speed control.
- Protect all surrounding areas from exhaust air
- Under normal condition motors may be operated at temperatures up to 250 F (121 C)
- Under Hazardous conditions: Motors should not exceed 104 F (40 C)

#### Lubrication

Use Gast #AD220 or a detergent SAE #10 automotive engine oil for lubricating. Lubricating is necessary to prevent rust on all moving parts. Excessive moisture in air line may cause rust or ice to form in the muffler when air expands as it passes through the motor. Install a moisture separator in the air line and an after cooler between compressor and air receiver to help prevent moisture problems.

#### Manual Lubrication

Shut the air motor down and oil after every 8 hours of operation. Add 10-20 drops of oil to the air motor intake port.

#### **Automatic Lubrication**

Adjust inline oiler to feed 1 drop of oil per minute for high speed or continuous duty usage. Do Not overfeed oil or exhaust air may become contaminated.

Each unit should have its own oiler mounted no more that 18-20 inches from the air motor.

#### **Cleaning the Air Motor**

Cleaning the air motor to remove excessive dirt, moisture, or particles that can occur in the operating environment will help maintain proper vane performance. Cleaning, or flushing the air motor, should occur only is the motor is operating slowly or inefficiently.

- Disconnect air line and muffler.
- Add flushing solvent directly into motor, If using liquid solvent, pour several tablespoons directly into the intake port. If using Gast recommended spray solvent, spray solvent for 5-10 seconds into intake port.
- Rotate shaft by hand in both directions for a few minutes.
- Wearing eye protection Cover exhaust with a cloth and reconnect the air line.
- Restart air motor at **low pressure approx 10 psi/0.7 bar –** operate the air motor at this rate until there is no trace of the solvent in the exhaust air.
- Listen to changes in the sound of the motor. If the motor sounds smooth, then the cleaning is complete. If the motor does not sound like it is running smoothly, installation of a service kit will be required.

# Randolph Austin Company

#### Vane part kit # 03-0373

Includes:

Replacement Vanes Gasket Bearing

# Estimated Ball Bearing Life of Lubricated Air Motors

Air Motor Model	Shaft Speed in RPM	Ball Bearing Life in hours L <sub>10</sub>
#03-0162	10000	28000

## **Spur Gear Reducer Specifications**

Motor #	Speed	Reduction	Max Allowable End Thrust with Zero Overhung Load	Max Allowable Overhung Load with Zero End Thrust (Output shaft Reducer)	Lubrication Gear Head
p/n 03- 0162	33.3 to 400 Rpm	15 to 1	100 lbs @ 333 rpm	100 lbs @ 333 rpm 200 lbs @ 33.3 rpm	300 ssu @ 100 F turbine quality oil sudh as: Gulf Harmony 53 Shell Tellus 33 Scocony DTE Humble Nuto 53

#### For horizontal operation:

Remove both plugs and add oil to top hole until other hole overflows.

#### For vertical operation:

Fill to overflowing point of upper most hole

## Guide for Troubleshooting Air Motor:

Low Torque	Low Speed	Won't Run	Runs Hot	Runs Well then slows down	Reason and Remedy
•	•	•			Dirt or foreign material present. Inspect and clean.
•	•	•			Internal Rust. Clean and Flush
•	•				Air pressure low. Increase
	•				Air line may be too small Install a lager line
	•			•	Restricted exhaust. Inspect and repair.
•	•	•		•	Jammed motor. Have motor serviced.
	•			•	Air source may be inadequate. Inspect and replace or repair
	•			•	Air source may be too far from motor. Change setup

1/22/2010

General Recommendations: Air Motor: #03-0362

#### Lubrication

Use Gast #AD220 or a detergent SAE #10 automotive engine oil for lubricating. Lubricating is necessary to prevent rust on all moving parts. Excessive moisture in air line may cause rust or ice to form in the muffler when air expands as it passes through the motor. Install a moisture separator in the air line and an after cooler between compressor and air receiver to help prevent moisture problems.

#### Manual Lubrication


Shut the air motor down and oil after every 8 hours of operation. Add 10-20 drops of oil to the air motor intake port.

#### **Automatic Lubrication**

Adjust inline oiler to feed 1 drop of oil per minute for high speed or continuous duty usage. Do Not overfeed oil or exhaust air may become contaminated.

Each unit should have its own oiler mounted no more that 18-20 inches from the air motor.

A filter, and regulator should also be used for each unit.



Flow curve established with water and a minimum lifting distance. Flow will be affected by fluid viscocity and lift distance.

# Randolph Austin Company Tubing Chemical Resistance Chart

Code indicates the percentage weight gain or loss after 24 hours immersion in the fluid.

(B) Best = 1-4%, (G) Good = 5-10%, (F) Fair = 11-15%, (P) Poor = 16%+

The data contained herein are based on tests conducted on representative samples and are considered accurate. The results should indicate liquids that could be used with the tubing. However no guarantee is given or implied regarding the application of this data to the safe use of the tubing. It is suggested that the purchaser conduct tests to determine if this material is suited to this application.

	Cilran™	ED-Plex™	Povinal ™	Prothane II ™	Vytex™
<u>Aqueous Solutions</u>					
Water	В	В	Р	В	В
Sodium Chloride (Saturated)	В	В	F	В	В
Aluminum Sulfate	В	В	Р	В	В
<u>Acids &amp; Bases</u>					
Sulphuric Acid (66° Be)	В	В	Р	G	В
Acetic Acid, Glacial	В	Р	Р	Р	F
Hydrochloric Acid (30° Be)	В	В	Р	Р	G
Nitric Acid (40° Be)	В	В	Р	Р	G
Sodium Hydroxide (50% sol.)	В	В	Р	В	В
Ammonia Hydroxide	В	В	Р	В	В
Aliphatic Hydrocarbons					
Diesel Fuel	Р	Р	В	G	G
Naptha	Р	Р	В	G	G
Mineral Oil	Р	Р	В	G	В
<u>Aromatic Hydrocarbons</u>					
Toluene	Р	Р	В	Р	Р
Xylene	Р	Р	В	Р	G
Chlorinated Solvents					
Trichloroethylene	Р	Р	В	Р	Р
Carbon Tetrachloride	Р	Р	В	Р	Р
Methylene Chloride	Р	Р	В	Р	Р
Ketones					
Acetone	В	В	F	Р	Р
Methyl Ethyl Ketone (MEK)	G	G	F	Р	Р
Esters					
Amyl Acetate	Р	В	F	Р	Р
Butyl Acetate	Р	В	F	Р	Р
Ethyl Acetate	Р	F	F	Р	Р
Alcohol					
Butyl Alcohol	G	G	Р	G	В
Isoproply Alcohol	G	В	F	В	В
Methyl Alcohol	В	В	F	G	В
Ethyl Alcohol (90%)	В	В	G	G	G
Glycol					
Ethylene Glycol	В	В	G	В	В
Glycerine	В	В	G	В	В
Vegetable Oil		_			6
Safflower Oil	В	В	В	В	G

# Summary – Physical Properties of Randolph Austin Extruded Tubing

#### Physical Tubing Properties – Cilran ™

Specific Gravity	0.90
Tensile Strength(psi)	928
Ultimate Elongation (%)	374
Hardness(Shore 'A' Scale +/- 2)	55
Normal Working Temperature (F)	(-40° to 190°)
Tensile set @ 100%	11.9%
100% Modulus (psi)	20
Compression set(%)	103
Tear Strength(lbs per inch)	386

Cilran <sup>™</sup> is made from a thermoplastic elastomer which possesses exceptional chemical resistance to acids and bases. Cilran <sup>™</sup> has low gas permeability, good flex fatigue resistance and meets USP Class VI specifications. Ideal for use in many laboratory applications, it may be used in place of silicone for some applications. Cilran <sup>™</sup> is translucent white in color and available in lengths up to 500 feet.

#### Physical Tubing Properties – Prothane II ™

Specific Gravity	1.18
Tensile Strength(psi)	2434
Ultimate Elongation (%)	870
Hardness(Shore 'A' Scale +/- 2)	68 A
Normal Working Temperature (F)	
Tensile set @ 100%	7.2%
100% Modulus (psi)	380
Compression set(%)	19
Tear Strength(lbs per inch)	274
Color	Aqua-Blue

PROTHANE II <sup>™</sup> is a transparent, aqua blue, polyester polyurethane tubing that exhibits excellent abrasion resistance, has good low temperature properties and is resistant to ozone and oxidation. PROTHANE II <sup>™</sup> exhibits an excellent resilience to continuous flexing and impacting experienced in peristaltic pumps. Along with these exceptional features PROTHANE II <sup>™</sup> exhibits good hydrolic stability, good oil and fuel resistance and high tensile and tear strength. PROTHANEII <sup>™</sup> is resistant to diesel fuel, kerosene, motor oil, mild solvents, aromatic hydrocarbons, gasoline, and concentrated acid and alkaline solutions. The tubing should be tested with the chosen fluid in all cases

# Summary – Physical Properties of Randolph Austin Extruded Tubing

#### Physical Tubing Properties – ED-Plex ™

Specific Gravity	0.98
Tensile Strength(psi)	928
Ultimate Elongation (%)	374
Hardness(Shore 'A' Scale +/- 2)	65
Normal Working Temperature (F)	(-40° to 190°)
Tensile set @ 100%	11.9%
100% Modulus (psi)	386
Compression set(%)	20
Tear Strength(lbs per inch)	103

E-D Plex <sup>TM</sup> is a multi-purpose tubing that is ideally suited for applications which range from transferring paint, ink, acids and bases. Some oil and hydrocarbons will work with E-D Plex <sup>TM</sup>, but should be tested before use. Combining the environmental resistance of EPDM with the chemical resistance of chloropreme, E-D Plex <sup>TM</sup> possesses similar elastomeric performance found in more expensive vulcanized rubber, while still maintaining high flex fatigue resistance.. E-D Plex <sup>TM</sup> has been proven very successful in peristaltic pump applications where continuous flexing is required.

#### Physical Tubing Properties – Vytex ™

Specific Gravity	1.18
Tensile Strength(psi)	1936
Ultimate Elongation (%)	465
Hardness(Shore 'A' Scale +/- 2)	60
Normal Working Temperature (F)	(-34° to 165°)
Tensile set @ 100%	97%
100% Modulus (psi)	484
Compression set(%)	N/A
Tear Strength PPI	115

Vytex <sup>™</sup> is a clear flexible polyvinyl tubing ideal for general purpose usage in applications with dilute aqueous solutions (both acids and alkali's) and for food and beverage usage. Strong acid solutions may be used with Vytex <sup>™</sup> for short intervals, but should be flushed with water after use. The smooth surface allows for easy flushing and cleanup for food and beverage applications. Vytex <sup>™</sup> is a durable, high flex tubing with a Shore "A" durometer of 60 allowing a long life expectancy for continuous flexing where peristaltic pumps are used. Available in lengths up to 500 feet.

# Summary – Physical Properties of Randolph Austin Extruded Tubing

#### Physcial Properties – Povinal ™

Specific Gravity	1.01
Tensile Strength(psi)	928
Ultimate Elongation (%)	374
Hardness(Shore 'A' Scale +/- 2)	65
Normal Working Temperature (F)	(15° to 125°)
Tensile set @ 100%	11.9%
100% Modulus (psi)	386
Compression set(%)	20
Tear Strength(lbs per inch)	103

Povinal <sup>TM</sup> is a polyvinyl alcohol based tubing which is excellent for use in applications with aliphatic, aromatic and chlorinated hydrocarbon solvents. Povinal <sup>TM</sup> has good flex fatigue resistance and is suitable for many industrial applications. It may be used as a substitute for fluroelastomer polymers in some applications. Not recommended for use with water or solutions containing concentrations of water. Available in lengths up to 500 feet. Pump tubing is teal in color. Transfer tubing is amber.

- 1. Turn power off. Remove side plate and tubing clamp. Remove existing tubing by manually turning rollers while gently tugging on the tubing.
- 2. Manually move rollers so that they are horizontal in relation to the base of the pump. Carefully insert tubing through the top tubing clamp section and the top of the pump housing. Manually turn the rotor in a counter clockwise direction until the roller begins to compress the tubing and begin feeding the tubing behind the bottom roller.
- 3. When the pump has moved ½ turn the tubing should be in a compressed state at the 9:00 o'clock position.
- 4. Return the side plate and tubing clamp to the pump. Tighten the knurled nuts on the side plate and tube clamp.

<b>Pump Series</b>	Tubing Size
250	.062" (3/16") ID x .187" (3/16") OD
250	.125" (1/8") ID x .250" (¼") OD
300	.250" ( ¼") ID x .437" (7/16") OD
400	.250" ( ¼") ID x .437" (7/16") OD
510	.187" (3/16") ID x .375" (3/8") OD
510	.250" ( ¼") ID x .437" (7/16") OD
610, 615, 620	.375" (3/8") ID x .625" (5/8") OD
610, 615, 620	.500" ( ½") ID x .750" (3/4") OD
750	.625" (5/8") ID x .937" (15/16") OD
750	.750" (3/4") ID x 1.062" (1 1/16") OD
880	.750" (3/4") ID x 1.125" ( 1 ¼") OD
880	1.00" (1") ID x 1.500" (1 ½") OD

Tubing sizes and capacities of the Randolph Pump:

# MATERIAL SAFETY DATA SHEET

#### PRODUCT NAME: Tube Lube PRODUCT CODE: N/A

Date: Nov-02-2001

#### **SECTION I**

#### HAZARDOUS INGREDIENTS

Ingredient None (at this time) Percent

TLV

#### SECTION II

#### HEALTH HAZARDS

# Threshold Limit Value: N/E

Effect of Overexposure

**Eyes**: Prolonged exposure may cause eye irritation. **Skin**: Prolonged exposure may cause skin irritation **Inhalation**: UNK **Ingestion**: Harmful if swallowed in sufficient quantities.

#### **First Aid**

**Eyes:** Flush with plenty of water for 15 minutes while lifting eyelids to insure entire eye surface is washed. **Skin:** Wash with soap and water

Inhalation: UNK

Ingestion: Consult physician.

Other Information: None

#### **SECTION III**

#### SPECIAL PROTECTION INFORMATION

**Respiratory Protection:** No special respiratory protection is required under normal situations. During the generation of large quantities of oil mist, use a MSHA/NIOSH approved respirator. **Ventilation Requirement**: No special ventilation is required

Protective Clothing:

**Eyes:** Normal Protection against foreign substances – safety goggles. **Skin:** Chemical resistant gloves should be used

Additional Protective Measures: Eye Wash Station and safety shower should be provided

#### **SECTION IV**

#### FIRE AND EXPLOSION HAZARD DATA

Flash Point (Method): 540 ° F (c.c.)

Flammable Limits (% Volume in Air): N/A Upper: N/A Lower: N/A

**Extinguishing Media:** Water – Fog, Foam, Carbon Dioxide and Dry Chemical **Special Fire Fighting Procedures:** Standard fireman's body protection. Self-contained breathing apparatus must be used to protect from products of combustion.

Unusual Fire and Explosion Hazards: Keep away from heat, sparks and open flame

# MATERIAL SAFETY DATA SHEET

#### **SECTION V**

#### PHYSICAL DATA

Boiling Point:N/ASpecific Gravity (Water =1): 0.959VEvaporation Rate:N/ASolubility in Water:UNKVpH:UNKWeight per Gallon:7.95 lbsPer Gallon:

Vapor Pressure (MM HG): UNK Vapor Density (Air =1): N/A Percent Volatile by Volume: N/A

Appearance and Odor: Light Yellow, Oily, No Apparent Odor

#### **SECTION VI**

#### **REACTIVITY DATA**

Stability: Stable Incompatibility: N/A

**Conditions to Avoid:** Keep from contact with oxidizing materials.

**Hazardous Decomposition Products:** Product of incomplete combustion can include CO, CO<sub>2</sub> and dense smoke.

Hazardous Polymerization: Will not occur.

#### **SECTION VII**

#### SPILL AND LEAK PROCEDURES

Steps to be taken if material is released or spilled: Soak up spill with sand, earth or sawdust. Flush with detergent and water.

Waste Disposal Method: Dispose of in accordance with Federal, State and local regulations

#### SECTION VIII

#### **D.O.T. SHIPPING INFORMATION**

**Proper Shipping Name:** None **ID Number:** None **Other Information:** None Hazard Class: None Label Requirements: None

#### **SECTION IX**

#### **ADDITIONAL INFORMATION**

This information may be of importance to you:
Precautions to be taken in handling and storing: Store in closed containers, protect from moisture and foreign matter. Keep away from heat and excessively warm areas.
Other precautions: Do not transfer to unmarked containers.
Conditions to Avoid: Keep from contact with oxidizing materials

N/A = Not Applicable N/D = Not Determined N/E = Not Established UNK = Unknown

Date Issued: 03/07/1986 Date revised: 11/01/2001