# NoiseMeters

# Acoustic Calibrator - Class 2, 114 dB



### Features

- IEC 60942:2003 Class 2
- ANSI S1.40:2006
- Sound pressure level 114 dB
- Frequency 1 kHz
- Fits 1/2" microphones

### Applications

- Calibration of noise dosimeters
- Calibration check of occupational noise meter
- Field calibration checks
- Required by many noise regulations

### Overview

The CR518 Acoustic Calibrator meets ANSI S1.40:2006 and IEC 60942:2003 to Class 2. It is intended for use with noise dosimeters and occupational noise meters that may require the higher calibration level.

This calibrator is included with the doseBadge Professional range of noise dosimeter kits, along with the doseBadges, charger, carrying case and software.

### **Using It**

As soon as the calibrator is switched on it emits a 1 kHz tone at 114 dB. The calibrator should be pushed carefully (firmly, but slowly) on to the microphone.

The meter should now be adjusted accordingly. There will often be a free-field adjustment to make for the microphone in use. So, for example, you may actually be adjusting to 113.8 dB on the meter. Meters like the doseBadge Pro make these adjustments automatically and deal with any corrections needed.

# **NoiseMeters**

## Acoustic Calibrator - Class 2, 114 dB

# **Specifications**

Standards

Sound Level Frequency Distortion Reference conditions Microphone size IEC 60942:2003 Class 2 ANSI S1.40:2006 114.0 dB ± 0.4 dB 1 kHz ± 1% < 2% 23°C, 101.3 kPa, 65% RH ½" (to IEC 1094-4) Battery type Dimensions Weight Controls

CE classification 1 x 9v (PP3, 6LR61, 6F22) 121 x Ø47 mm 220 g with battery Push button start, Automatic switch off with green LED indication. User override of automatic switch off EN 61000-6-3:2007+A1:2011

EN 61000-6-1:2007

### Head Office

NoiseMeters Inc 3233 Coolidge Hwy Berkley MI 48072 USA

Telephone **888 206 4377** Fax **888 584 2230** 

Email: info@noisemeters.com Support: support@noisemeters.com

### Web Sites

Main site: https://www.noisemeters.com

Product shortcut: https://www.noisemeters.com/p/cr518/

Tech Support: https://support.noisemeters.com